



To use the Computer / Projector

1. Turn on the projector using the POWER button on the podium panel.
2. Select the LOCAL COMPUTER input channel on the podium panel.

To use a Laptop / Projector

1. Connect the VGA and audio cables on the left side of the podium to the laptop.
2. Turn on the projector using the POWER button on the podium panel.
3. Select the AUX COMPUTER input channel on the podium panel.

To use the Document Camera / Projector

1. Turn on the projector using the POWER button on the podium panel.
2. Turn on the Document Camera by pressing the large power button located on the front section of the document camera.
3. Select the Doc Cam input channel on the podium panel.
4. Note that the VCR must have power for the Document Camera to display through the projector.