TYPICAL TEC CLASSROOM CONNECTOR PANEL (ALSO KNOWN AS INPUT PANEL)



GENERAL RULES OF THUMB:

#1 Connect ALL required cables first
#2 Boot laptop (or whatever computer you are using)
#3 Then turn on A/V System with DISPLAY POWER button (Projector will emit a light after a few seconds - be patient)
#4 You may have to turn on the AUDIO manually, make sure GREEN light on CONNECTOR PANEL is lit
#5 If image doesn't project initially, check that the COMPUTER input is selected, use the laptop Fn/F7 or Fn/F8 to toggle on
#6 If still no image, select DVD, turn DVD player on and see if you see the DVD start-up screen (This will verify that the projector hasn't been tampered with)
#7 If still no image try different VGA cable (Remember, ANY cable will wear out or break)
#8 Call x8953 for help if you still can't get an image
#9 Using the WIRED network is preferred over the WIRELESS because of speed and reliability
#10 If a Microphone is needed, call X6610 to sign one out
#11 If there seems to be a lot of noise in the audio, make sure the MIC VOLUME is turned all the way down if not being used
#12 Turn OFF the system when done